

# ZilenziO

Selling silence

## Installation instructions - Timber wall absorbent

Timber wall absorber mounted up with Velcro plates that stick to the wall. It comes with a Velcro flatter each absorber. Pat plate is 300mm shorter than the absorber is. If there is to be fitted up a large number of absorbers, like the image to the right so it works perfectly possible to assemble the plates horizontally and then not use as many plates.

